

BUTTERFLY VALVE

Serie BSV ...

The butterfly valves of the series BSV are DVGW approved to the norms EN 161 and bear the CE Product - I D - Number. They are suitable to be used on residential and industrial combustion systems.

They are particularly suitable for both manual and automatic control of gases belonging to the first, second and third family and of air.

Installation with two threaded flanges ranging from Rp 3/4 to Rp 2.





TECHNICAL FEATURES

Max. pressure	: 300 mbar	Body and flanges	: aluminium
Ambient temperature	: -10 ÷ +60 °C for gas -10 ÷ +80 °C for air	Stem	: stainless steel AISI 303
Flanges	: threaded ISO 7-1:1982 from Rp 3/4 to Rp 2	Butterfly disc	: aluminium
Control ratio	: 10:1	Stem sealing	: "O" ring in perbunan - NBR

FEATURES

- Sturdy, compact construction, specially suitable for industrial applications
- Installation in any position.
- Mechanical position indicator.
- Lockable rotation angle from 0° to 90°.
- Without zero setting.
- External tightness by means of two "O" rings.
- Easy conversion on field from manual to automatic servicing.
- Wide range of accessories on request:
 - manual control lever.
 - 1 or 2 internal reductions with respect to the nominal diameter of the valve.
 - Elliptic-shaped or moulded butterfly.
 - VITON seals for air temperatures up to 110°C.



BSV FLOW CHART



DN	Rp	Orifice diameter (mm)	MODEL	
			Manual control	Free shaft
20	3/4	20	BSV20.A	BSV20.B
25	1	20	BSV25/20.A	BSV25/20.B
		25	BSV25.A	BSV25.B
32	1 1/4	20	BSV32/20.A	BSV32/20.B
		25	BSV32/25.A	BSV32/25.B
		32	BSV32.A	BSV32.B
40	1 1/2	25	BSV40/25.A	BSV40/25.B
		32	BSV40/32.A	BSV40/32.B
		40	BSV40.A	BSV40.B
50	2	32	BSV50/32.A	BSV50/32.B
		40	BSV50/40.A	BSV50/40.B
		50	BSV50.A	BSV50.B

DIMENSIONS (mm)

BSV... . A



INSTALLATION AND MAINTENANCE INSTRUCTIONS

1. **WARNING**

Installation, adjustment and maintenance of the valve must be carried out exclusively by skilled and authorized service technicians.

Non proper installation, adjustment, changes, use and maintenance may cause damages to the personnel or to the equipment. Consequently it is necessary to respect strictly the following instructions and local prescriptions for both the installation of electric devices, in case of motorized valves, and of gas systems.

2. **INSTALLATION**

- 2.1 Make sure that all operating data indicated on the valve plates correspond to those of the system.
- 2.2 When installing the valve be sure that there is sufficient clearance above the gear cover and that it can be easily accessible in order to perform manual servicing, automatic servicing by means of a gear motor or servicing by means of levers.
- 2.3 For the valves of the BSV series proceed as follows:
 - remove the protection plugs from the threaded flanges,
 - screw the threaded flanges to the inlet and outlet pipes, using exclusively sealing materials suitable for gases,
 - insert the BSV valve between the two flanges with "O" rings,
 - tighten the flanges to the valve body by means of the respective bolts.
- 2.4 The installation of the BSV valves can be performed in any position.
- 2.5 The valve can be installed in any location except where acid fumes or other deteriorating vapour may attack its metal parts or where gas leaks or explosive vapours are present in the atmosphere.
- 2.6 Do not use the valve as a lever.

3. **OPERATING**

- 3.1 Before operating the following points must be checked carefully:
 - Tightness of the external gas pipes.
 - That valve adjustment is performed within the requested angle range.
 - That mechanical locks or other retainers which may damage the valve have been removed.
- 3.2 Once these preliminary checks have been performed, the main gas tap can be opened and the operation test can be carried out.

4. **MAINTENANCE AND CHECKS**

- 4.1 The BSV valves do not require any particular current maintenance because they do not need lubrication.
- 4.2 It is recommendable to check at least once a year that the mechanical connections have not been modified, especially in case of systems which do not function vibration-free.

5. **REPLACEMENT**

In case replacement of the valve is necessary, proceed as follows:

- 5.1 Close the main gas tap.
- 5.2 Remove the mechanical connections from the valve axis.
- 5.3 Remove the valve body from the inlet and outlet flanges by loosening the fastening screws from the respective nuts.
- 5.4 Install the new valve proceeding as per instructions reported in the foregoing chapters.

All the reported data are subject to be changed without notice.



Via F. De Sanctis, 53 - I - 20141 MILANO - Tel. +39 0289502912 - Fax. +39 028463084 - E-mail: econex@tin.it - www.econex.it